

ROITHNER 532

v1 02/14

- Green DPSS Laser Pointer
- 532 nm, <5 mW
- IR Filter
- Laser Class 3R



Description


ROITHNER 532 is a diode pumped solid state (DPSS) laser pointer emitting at 532 nm with rated output power of <5 mW, utilizing a 808 nm pump laser diode with Nd:YVO4 crystal and IR filter. An integrated Automatic Power Control (APC) unit with direct 532 nm feedback loop ensures excellent output power stability. ROITHNER 532 features an indicator LED for safe operation, and is run by 2 x 1.5V AAA alkaline batteries. It comes in a polished chrome metal housing. → Transport case and batteries included

Specifications

Parameter	Values			11-24
	Min.	Тур.	Max.	Unit
Wavelength		532		nm
Output Power	3		5	mW
Laser Class	3R			
Beam Mode	TEMoo			
Operating Temperature	20		30	°C
Operating Humidity (rel.)	40		70	%
Storage Temperature	-20		60	°C
Body Material	brass, polished chrome finish			
Lens Material	PMMA			
Weight (incl. batteries)	75			g
Power Source	2 x 1.5 V AAA alkaline batteries			



Outline and Components



No.	Function
1	laser beam outlet
2	laser push button (ON/OFF)
3	battery compartment

www.roithner-laser.com

Safety Instructions

- . This laser is intended for pointing out details on objects/blackboards during lecturing
- Laser radiation, direct and indirect can be dangerous to the naked eye
 - o Before operating the laser pointer make sure nobody is in or near the projection area
 - o Do not look into the laser beam
 - Do not point the laser into the sky
 - o Do not point the laser towards other humans or animals
 - o Do not point the laser towards vehicles
 - o Do not point the laser at mirrors or any reflective surfaces
- . Do not expose the laser pointer to high temperature, moisture, or vibration
- Do not give the laser pointer to unauthorized persons
- Do keep the laser pointer out of the reach of children
- Do not open the device. Maintenance must only be carried out be qualified personal
- This product is a class 3R laser device (EN 60825-1:2007)



Insertion/Replacement/Disposal of Batteries

- Do only use brand new 1.5V AAA (micro) batteries of good quality
- · Make sure batteries are inserted with correct polarity
- · Batteries must not be short circuit or thrown into the fire
- Do not attempt to recharge the batteries
- · Do not mix batteries of different charge state



As the end user, you are required by law, to return all flat batteries to your local waste collection place. Disposal of batteries in the household waste is prohibited

→ Protect your environment

Operation



Do never point the laser beam directly at persons/animals/vehicles

- The laser pointer is switched ON and OFF by means of a push button (2)
- If the push button (2) is pressed, the laser radiation emits through the laser outlet (1)
- If the push button (2) is released, the laser radiation is stopped



This laser pointer has been designed for intermittent use. If operated over 3 minutes
continually, the temperature of the internal pump laser diode may exceed critical
threshold, thereby negatively affecting the laser pointers performance and life time

Disposal



Disposal of an unserviceable product has to be made in accordance with the relevant statutory regulations effective in your country

© All Rights Reserved

The above specifications are for reference purpose only and subjected to change without prior notice

www.roithner-laser.com 2